

## XXIII. MAINTENANCE

All our diffusers are made of high-quality resistant materials without a natural fibre admixture. The used material is specified when your order is technically processed. The diffusers made of permeable fabric (PMS, PMI, PLS, PLI) can be washed in a common industrial washing machine. Impermeable fabrics (NMS, NMI, NLS, NLI) require a gentle mode washing, fabric NMF, NHE and NLF hand washing only. If the washed diffuser has tyres, braces or turn-buckles, these solid elements must be removed before the washing process. Induction surface dirt (see article XXI) can be vacuumed, washing is unnecessary.

### The process of washing:

**Strictly follow the maintenance symbols indicated on the labels sewn near the zips in the diffusers.**

### We recommend:

1. Wash the diffusers with common detergents (dosing according to the directions for use), the effect of washing is enhanced if the diffuser is turned inside out. We advise you to repeat the washing up to four times acc. to level of contamination, or to use more powerful washing powder. A special detergent (we will recommend one by request according to the particular dirt) should be used if the fabric is badly soiled.
2. Use a disinfectant only if it is essential according to the local service instructions. The chemical composition of the disinfectant must not harm the diffuser fabric (see maintenance symbols). Observe the producer's dosing instructions.
3. Rinse the diffusers in clean water.
4. Spin-dry the diffusers gently, install them and finish drying by the air flow from the ventilator.

### Symbols key:

	max. temperature for washing 40°C normal mechanical action normal rinsing normal separating
	gentle washing in a washing machine, maximum temperature 40 °C, gentle mechanical action, rinsing in water cooling down, gentle spin-driing
	washing only by hands product must not be washed in washing machine max. temperature 40°C cautious handling
	product must not be whitened
	dry in a drum-drying machine use lower temperature of drying
	product can't be dryed in a drum-drying
	ironing within of max. temperature of ironing surface 110°C, cautious with steam ironing
	product must not be ironned steaming is inadmissible
	product must not be dry cleaned the stains must not be removed by organic solvents
	product can be dry cleaned with tetrachlorethen, and all solvents mentioned with symbol F